

wirata®

INSTRUCTION MANUAL

Model No.:

TP-153A

Please read *Instruction Manual* before use
& Follow ALL the instructions carefully.

MODEL NO.	TP-153A
Power Consumption	730W
Voltage	220-240V
Frequency	50-60Hz
Volume Capacity	3.2L

WHAT'S IN THE BOX

1. Thermo Pot – 1set
2. Power cord – 1pc
3. Instruction Manual – 1pc

PARTS DESCRIPTION

MAIN COMPONENT :

(Product may vary slightly from what is illustrated)



GENERAL INSTRUCTIONS

When using the electrical appliance, the following basic safety precautions should always be followed. Please read these instructions carefully. Pay your special attention to important safety instructions. Keep this "**Instructions for use**" for future reference.

SAFETY INSTRUCTIONS


If you are using the thermopot for the first time, it is recommended that you clean your thermopot before use by boiling a full kettle of water twice and then discarding the water.

1. Read all instructions before using.
2. Never immerse the appliance in water or any other liquids, nor rinse it under the tap.
3. Check if the voltage indicated on the appliance corresponded to the local mains voltage before you connect the appliance.
4. Do not operate the appliance with damaged power cord or plug, after appliance malfunctioned, or if it is dropped or damaged in any matter. Return.....adjustment
5. Wait until the appliance has cooled down before cleaning, removing or replacing the lid.
6. Take extreme care when removing the appliance if it contains hot water.
7. This appliance is not intended to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
8. Children should be supervised to ensure that they do not play with the appliance.
9. Always use the appliance on a flat, stable and heat resistant surface to prevent the power cord from coming into contact with hot surfaces.

10. Unplug the appliance before cleaning and when problems occur during dispensing.
11. Never over filling water into the water tank as it may cause splash. Refer to the "full" water level mark in the water tank.
12. Keep hands or any part of your body from the water outlet for a second or two right after you press the dispense button as hot water emitted from the water outlet may splash.
13. This appliance is for household or domestic use only.
14. Do not use the appliance outdoor.

WARNING: Never open the lid when water is boiling!

HOW TO OPERATE




1. Wash and rinse water tank with water.
2. Fill water up to full mark.
3. Boil once and discard the water (press the unlock button once and then press the dispense button).

A. Remove & Attach the lid:


Detach Lid

Place the handle towards the rear side of the thermopot. Then open the lid by pulling up the lid opening lever (caution: be careful of the steam from the steam vent). Position the lid at 45° and pull out the lid from the hinge holder by pressing the hinge lock at the rear of the lid. Note: Never remove the lid while the water is boiling.




Attach Lid

Place the handle towards the rear side of the thermopot. Press the hinge lock, at the same time insert the shaft of the hinge of the lid into the hinge holder. Ensure that the lid is attached properly and close the lid until it clicks.



To open the lid and fill water

Pull the lid opening lever up to open the lid and fill water into the water tank.



- Always fill water above the minimum water level mark and below the maximum water level mark.
- Refer to the water level mark in the water tank.


To close the lid

Close the lid by pressing down until it clicks.

- Do not close the lid by force.

1. Insert the connector into the power inlet.
2. Then, insert the plug into the wall outlet.

WARNING: Do not power on the appliance if the water tank is empty.




- Connect the plug to the power inlet horizontally.

To boil water


After power on the thermo pot, "boil" (in red)

- Do not open the lid or dispense water while the water is boiling.
- Do not add water when water is boiling.
- Do not contact any parts of your body to the steam vent.
- Do not place cloth or any other items to cover the steam vent.

<p>Keep warm</p> <ol style="list-style-type: none"> 1. The keep warm function will be activated and the “keep warm” light indicator (in green) will turn on after water boiled. 2. Press the “re-boil” button if cold water had been added or if you wish to re-boil the water again. 	
<p>Dispense hot water</p> <p>1. Dispense button</p> <p>a) Press the “dispense” button to dispense hot water.</p> <p>Note: The hot water may not dispense immediately right after boiling. Keep pressing until the water is dispensed.</p>  <p>2. Cup switch</p> <p>a) Push up the cup switch with your cup to dispense hot water.</p> <p>Note:</p> <ul style="list-style-type: none"> • If the dispense button is not selected within 10 seconds after selecting the unlock button, the appliance will automatically revert back to the locked position. • The dispensing function will NOT operate if the thermo pot is not connected to the main switch. 	<ul style="list-style-type: none"> • CAUTION: Always keep hands or any parts of your body from the water outlet for a second or two right after you press the dispense button. • Do not press the dispense button when the inner water reservoir is empty. • You cannot dispense hot water by pressing the dispense button, or cup switch if the thermo pot is unplugged.
<p>Refill water</p> <p>When water level is low, add water for automatic re-boil.</p>	<ul style="list-style-type: none"> • Do not add water above maximum water level mark. Boil water with insufficient may cause malfunction.

To re-boil water under keep warm mode

1. Press the "re-boil" button once. "Boil" light indicator (in red) will be on.
2. After re-boiling process is completed, the keep warm light (in green) will turn on.
 - ❖ Re-boil will not function if there is insufficient water inside the water tank.
 - ❖ Press the re-boil button immediately after the water boiled will have no effect as the water is already at the temperature of 100°C.



- It will take about 3 minutes to re-boil water (with full water tank).
- Before re-boiling the water, make sure the water level is above the refill mark.
- When adding water into the water tank, be careful of the hot steam from steam vent and water tank.
- Once the re-boil button is pressed, the boiling process will begin and you cannot reset any button until it turns to keep warm mode.
- Do not press the re-boil button continuously (after re-boiling process) as it may cause malfunction.


AUTO CUT-OFF:

- a) When the water boil dry, the thermo pot will automatically cut off the power.
- b) The auto CUT-OFF function will also operate when:
 - The power is switched on, but no water is filled in the water tank.
 - Water level is below the MIN water level mark.

CLEANING INSTRUCTION

1. Always allow appliance to cool down before cleaning.
2. Remember to unplug the plug from wall socket and power inlet.
3. Open the lid and pour out the remaining water in the water tank.

Wipe the lid and body with a damp cloth.



- Never immerse any part of the thermo pot in water.
- Never splash water on the control panel.
- Do not use abrasive materials to clean the appliance.



Discoloration of the water tank and white floating objects in the water tank.






- Red rust-like spots, milky or black discoloration, and white floating objects are caused by minerals in the water and are not caused by discoloration or deterioration of the water tank itself. Although this is not a hygiene problem, you are advisable to clean the water tank periodically.
- Cut a lemon into four pieces and wrap the lemon in the cloth then put in the water tank.
- Pour water up to the full level mark in the water tank.
- Boil the water and then retain the heat for about one hour.
- Pour out the water and use a nylon brush to clean the water tank.

	<ul style="list-style-type: none"> To remove the smell of the lemon, you can boil the water again and dispose the water.
Stainless steel water reservoir	<ul style="list-style-type: none"> Wash the water tank with a sponge and then rinse with clean water. IMPORTANT: Do not use the following to clean the container. Dish soap (this causes an unpleasant odour) Scrubbing powder or scrubbing brushes (it will damage the container and lid) Benzene (it will cause damage to the plastic of the lid)

HAZARDS

	Do not immerse the thermo pot, power cord or plug in the water or any other liquids to prevent electric shock.
	Do not place the thermo pot on unstable surfaces.

	<p>Fill the water tank with tap water (do not fill with milk or any other liquids).</p>
	<p>Do not fill the thermo pot with water above the full mark inside the water tank or lower than the minimum water level to avoid damage to the appliance.</p>
	<p>Do not place the thermo pot on or near to hot surface.</p>

IMPORTANT GUIDELINES

WARNING: THIS APPLIANCE MUST BE EARTHED

The wires in this main are coloured in accordance with the following code:

Green & yellow: Earth
Blue: Neutral
Brown: Live

If the colours above do not match those terminals identified of the plug, connect as follows:

- The wire with the colour of green and yellow must be connected to the terminal marked "E" or by the earth symbol, green colour or green and yellow colour.
- The wire with the colour of blue must be connected to the terminal marked N or black colour.
- The wire with the colour of brown must be connected to terminal marked L or red colour. (If terminals of plug are unmarked or if any doubt, kindly consult qualified electrician for assistance).



ENVIRONMENT PROTECTION

Dispose the appliance according to the local garbage regulations. Never throw it away to the rubbish, so you will help to the improvement of the environment.