

# wirata<sup>®</sup>

## INSTRUCTION MANUAL

Model No.:

**R-882, R-883**

Please read *Instruction Manual* before use  
& Follow ALL the instructions carefully.

<b>MODEL NO.</b>	<b>R-882</b>	<b>R-883</b>
POWER	1000-1200W	1000-1200W
VOLTAGE	220-240V	220-240V
FREQUENCY	50/60Hz	50/60Hz
WEIGHT	1.6KG	2.0KG

## WHAT'S IN THE BOX

1. Electric Heavy Iron – 1pc
2. Instruction Manual – 1pc

## PARTS DESCRIPTION



### MAIN COMPONENT :

(Product may vary slightly from what is illustrated)

- 1: Handle
- 2: Cord Cover
- 3: Temperature regulator
- 4: Soleplate

## GENERAL INSTRUCTION

When using the electrical appliance, the following basic safety precautions should always be followed.

Please read these instructions carefully. Pay your special attention to important safety instructions. Keep this “**Instructions for use**” for future reference.

## SAFETY INSTRUCTIONS

- Read the user manual before operating any appliance or equipment.
- To avoid risk of electric shock, do not immerse the equipment in water or use it in damp conditions.
- While plugging or unplugging a power cord, hold it by the plug. Never pull it by the cord.
- Do not operate any equipment with a damaged power cord.
- Check the voltage available at your home and ensure that it matches the voltage mentioned on your appliance before switching it on.
- Do not attempt to repair the unit in case of any malfunction. Always take it to an authorized service centre.
- Always keep the unit on a dry and flat surface.
- Do not use any attachments other than the ones supplied by or specified by the manufacturer.
- Always unplug the unit from the power source during lightning and thunderstorms or when the unit is not used for a long period of time.
- Never leave the unit unattended while in operation especially when children are around.
- All the equipment is for household use only. Do not use it for commercial purposes.

- All appliances and equipment are designed for indoor use. Do not use them outdoors unless specifically mentioned in the instruction manual.
- Do not connect the equipment to an extension cord or multiple socket adaptor. Always connect the unit to the main socket. This is to prevent short circuits and sparking which can shorten the life of the unit.
- Do not let the power cord to hang over the edge of the table or work surface since a sharp edge can damage the cable over a period of time. Do not let it get tangled or meet a hot surface.
- The units can be cleaned with a damp cloth and immediately wiped dry. Do not use detergents or chemical cleaning agents to clean the unit.
- Never touch any appliance or equipment with wet or damp hands.
- If power cord is damaged, please replaced by the service centre or the person who designated by the manufacturer or a qualified person to avoid electric shock.

**WARNING:** Do not use the device near water, over the bath tub, pool or other water basin.

\*Observe the above-mentioned rules in order to avoid burning, electric shock or fire hazard. Make sure you understand the instructions.



## HOW TO USE

- a) Set fabric dial at the desired fabric marking.
- b) Make sure the voltage indicated on the iron meets your local voltage. Allow iron to heat for 2 minutes on heel rest before ironing.
- c) The pilot lamps glows when the iron is switched on, and goes off when the iron is heated up to the temperature selected by the fabric dial. The lamp will remain off as long as the iron keeps the selected temperature and as

the temperature decreases, the thermostat will start working and the lamp will glow again. The thermostat makes the pilot adjust automatically to the varying temperature as being selected by the fabric deal.

- d) First iron chemical synthetic fabric at low temperature and then, as the temperature rise, iron wool, cotton and linen accordingly. The iron heats more quickly than it cool.
- e) Allow time for the iron to heat when changing from a low temperature to a high one. Conversely, wait a while when changing to cooler setting.

### CLEANING INSTRUCTIONS

- a) Before cleaning remove the main plug from the wall socket the iron to cool down sufficiently.
- b) The appliance can be cleaned with a damp cloth.



#### **ENVIRONMENT PROTECTION**

Dispose the appliance according to the local garbage regulations.

Never throw it away to the rubbish, so you will help to the improvement of the environment.