

wirata[®]

INSTRUCTION MANUAL

Model No.:

SP-20

Please read *Instruction Manual* before use
& Follow ALL the instructions carefully.

Model No.	SP-20
USB Soundbar Speaker	4Ω 3W*2
S/N	≥45dB
Power Input	DC 5V1A
Frequency Response	100Hz-20KHz
Input Sensitivity	700mv±50
Standby power dissipation	≤0.5W

WHAT'S IN THE BOX


1. Soundbar – 1set
2. Input cable – 1pc
3. Instruction Manual – 1pc

PARTS DESCRIPTION

1. Front view of speaker:



2. Volume Controller:



HOW TO OPERATE

1. Connect the soundbar auxiliary source and USB plug to your device.
2. **Volume Controller functions:**
 - a) Long press Volume Controller for power ON/OFF.
 - b) Single click for AUX / BLUETOOTH mode selection.
 - c) Double click for RGB lights ON/OFF.
3. To increase or decrease volume, kindly use the Volume controller to adjust main volume.
Notice: High volume can damage your hearing.
4. USB PLUG for PC Laptop/PC, Power Bank, Mobile phone Adapter.
5. 3.5mm Audio Interface for Tablet, Laptop/PC, Projector, Mobile Phone & etc.

WARNING

- Keep dry, do not expose to water, or put flowerpot nearby soundbar.



ENVIRONMENT PROTECTION

Dispose the appliance according to the local garbage regulations.

Never throw it away to the rubbish, so you will help to the improvement of the environment.